


January 2018

Standard Operating Procedures

Intensive Watershed Monitoring – Stream Water Quality Component



Authors

Pam Anderson

Kelly O'Hara

Lindsay Egge

Lee Engel

Editing and graphic design

Paul Andre

The MPCA is reducing printing and mailing costs by using the Internet to distribute reports and information to wider audience. Visit our website for more information.

MPCA reports are printed on 100% post-consumer recycled content paper manufactured without chlorine or chlorine derivatives.

Minnesota Pollution Control Agency

520 Lafayette Road North | Saint Paul, MN 55155-4194 |

651-296-6300 | 800-657-3864 | Or use your preferred relay service. | Info.pca@state.mn.us

This report is available in alternative formats upon request, and online at www.pca.state.mn.us.

Document number: wq-s1-18

Foreword

This document of standard procedures is specific to stream chemistry and bacteria sampling and field monitoring conducted by Surface Water Assessment Grant local partners. These procedures are applicable to Cycle II of the Intensive Watershed Monitoring Program.

Contents

Executive summary	1
Scope and application	1
Personnel qualifications/responsibilities	1
Summary of method	1
Cautions and interferences	1
Procedures	2
Pre-sampling requirements	2
Field meter sensor calibration.....	2
Equipment preparation	2
Equipment and supply checklist.....	3
Document preparation	3
Onsite procedures.....	4
Travel to sampling location	4
Sampling preparation	4
Field/lab datasheet completion	4
Photo	4
Field meter measurements	5
In-stream sampling – wading	5
In-stream sampling - shoreline.....	5
In-stream sampling - bridge	6
100 cm Secchi tube transparency measurement.....	6
Quality assurance/Quality control	7
Guidelines for collecting a field duplicate	7
Guidelines for collecting a field blank (equipment blank):	7
Chain of custody completion.....	7
Shipping preparation	7
Post-trip requirements.....	8
Processing photos.....	8
Data management	9
Field observations	9
Laboratory results	9
Health and safety	10
Chemical safety	10
Road and vehicle safety.....	10

Traffic control devices	10
General sampling safety	11
Appendix A – Preservation and holding times	12
Appendix B – Metadata coding for field observations in EQulS.....	13
Additional instructions/information	13

Executive summary

Scope and application

This standard operating procedure (SOP) is applicable to field observations and collection of water quality samples from streams and rivers for condition monitoring. This SOP details the steps necessary to prepare for stream monitoring, make proper field observations, collect and process water quality samples, and complete the proper documentation for sample delivery and analysis from a State certified lab.

Personnel qualifications/responsibilities

The Minnesota Pollution Control Agency (MPCA) and local partner's monitoring staff must be familiar with proper sampling techniques, sample handling, safety procedures, and record keeping. New staff and student workers/interns must be trained and accompanied in the field by experienced staff until competence is assured. Student workers/interns shall be provided written SOPs/instructions and one on one training at the start of their employment.

Summary of method

No single procedure will be applicable to all sampling situations (sampling from a bridge, shore, or wading); therefore, the sampler must make a judgment based on which would produce the most representative sample, considering safety and efficiency. Water samples from flowing surface waters should represent the flow in the stream, and not simply conditions that might occur in a small portion of the cross-section. Selection of one of the following methods should be based on access to a well-mixed, flowing portion of the stream, and the ability to pull water from below the surface without disturbing bottom sediments.

- **Hand-collected (grab) sample** – stream water is collected directly into the bottle in wade-able streams.
- **Telescoping rod** – collection of sample from shore or low bridge using a bottle attached to a telescoping arm.
- **Weighted bucket or Van Dorn/Kemerer sampler** – collection of sample from bridge – equipment lowered to water surface via a rope.

Under no circumstances are samples to be collected from standing or stagnant water. If there is no discernable flow, no sample shall be collected. Document the flow conditions and contact your project manager to report your observations.

Cautions and interferences

The sample may be contaminated if the sampling device is not properly rinsed prior to collection. For standard sampling equipment (i.e. telescoping rod, weighted bucket) the sample device should be rinsed three times with stream water prior to sample collection.

Sample contamination can also occur if bottom sediments are disturbed during collection. Should this occur, the sampling device must be emptied and rinsed. Move to a different location in the cross section or upstream to avoid collection of disturbed sediment.

Also, avoid touching the inner surfaces of the lid, bottle, and sampling equipment to reduce chance of contamination, especially for bacteria sampling.

Procedures

This section details the steps necessary to collect, process, and prepare samples for delivery to a state certified lab. Contractors must use laboratories listed within the [MPCA's Master Lab Services Contract](#). Contractors are expected to work directly with the lab for specific instructions on bottle rinsing, sample preservation, bottle labeling, and submission instructions.

Pre-sampling requirements

Field meter sensor calibration

Calibration is required for pH, conductivity, and dissolved oxygen (DO). A detailed calibration record, which documents pre and post monitoring information, is necessary for quality assurance/quality control (QA/QC). Calibrate DO each day of monitoring. Additional parameters shall be calibrated per manufacturer's recommendations but not to exceed 30 days during monitoring season. The frequency of recorded calibration checks is also determined by the amount of time observed for a particular sensor to drift beyond an acceptable difference from the measurement standard or, in the case of DO, the expected concentration at 100% saturation. It is prudent to check calibration daily until a sensor demonstrates that it will hold calibration for a longer period. Calibration resets should be performed according to the manufacturer's recommendation and recorded against standard solution or expected reading. Local partners may use the calibration form, located within the Surface Water Assessment Grant (SWAG) guidance webpage, and submit with progress reports. Alternative forms of documentation are acceptable and shall be discussed with the MPCA project manager.

Meter calibration records support the accuracy of the data collected using these instruments. For each parameter calibrated, a measurement must be taken on the standard solution prior to calibration and recorded in the "Before Reset" field. The value obtained from the sonde after the calibration will be entered in the "Reset Reading" field which corresponds to the parameter being calibrated. Also, record the expiration date of the calibration standard in the "Expiration Date" field, if applicable. Error readings or complications with the meter will be recorded in the appropriate box and the technician calibrating the sonde will sign off to indicate the calibration has been completed. Further comments for faulty meters shall be discussed with the MPCA project manager and documented within the progress report. A record of maintenance for each sonde must also be kept to increase the longevity of the equipment and insuring the accuracy of readings.

Equipment preparation

Equipment necessary to conduct a complete sampling trip should be gathered prior to departure. The required analyses and observations for each sampling are displayed in Appendix A. Confirm that the number of bottles and preservative necessary to complete all regular and duplicate sampling are packed. Use of a trip specific checklist of equipment and supplies is recommended.

The use of additional equipment and decontamination materials may be necessary when monitoring locations that are designated with an invasive species infestation. Samples collected in infested waters shall be labeled "AIS" in accordance with lab requirements to ensure proper disposal. Additionally, documentation shall be provided within the Chain of Custody (COC). See the MPCA procedures for sampling infested waters at the SWAG webpage.

Due to short E. coli holding times, it is recommended that the designated lab be notified of sample arrival 24 hours prior to delivery.

Equipment and supply checklist

A variety of sampling equipment is needed for surface water sample collection. The following checklist is a useful guide for sampling needs.

Check all electronic equipment and batteries for proper operation. If you have any doubts about the condition of a piece of equipment, bring along a replacement if available.

Field survival

- First aid kit
- Insect repellent (wash hands thoroughly after applying)
- Rain gear
- Personal floatation device (PFD)
- Cell phone
- GPS unit (optional)
- Replacement batteries
- Toolbox with basic tools

Field equipment

- Camera
- 100 cm Secchi Tube
- Calibrated field meter with pH, specific conductance, temperature, and DO probes
- Field notebook or field sheet
- Waterproof pens, markers and/or pencils
- Chain of Custody form

Surface water sampling equipment

- Sample bottles (including extra sets)
- Telescoping rod, 12 foot and/or 24 foot
- Weighted bucket, Van Dorn or Kemmerer sampler
- Spare parts for repair of samplers
- Coolers and ice
- Permanent markers
- Hip waders or wading boots

Equipment decontamination

- Distilled water
- Sprayer

Document preparation

Prepare stream monitoring data sheets with specific site/date information relevant to the sampling event. Note that information recorded on the stream monitoring data sheet will be transcribed to EQUIS at a later date. It is imperative that accurate documentation occurs at this step to prevent future errors.

Prior to any field monitoring preparations, all local partners shall obtain guidance from their designated laboratory regarding appropriate bottle labelling and completion of the COC. Local partners may complete COC's prior to sampling trips for trip planning guidance. In this instance, local partners may submit to MPCA project manager for prior review. Indicate the correct EQUIS Project (PRJ) code, contact information, site information, and designated analyses and bottles details for each specific monitoring location. When relevant, include field replicates and sampler blanks for quality control. Label bottles prior to filling and provide identifying information in accordance with instructions provided by the analytical laboratory.

Onsite procedures

Travel to sampling location

Travel to the sample location(s) with the assistance of a GPS unit or map. Wherever possible, park the vehicle in a nearby field approach or public parking lot. If these options are not available, park on the road shoulder, ensuring the vehicle is clear of the traffic lane and follow instructions detailed within the Health and Safety section.

Sampling preparation

Bottles, camera, 100 cm Secchi tube, water sampling device, and field sheets/notebook/pen should accompany the samplers to the sample location as needed. Identify appropriate sample collection location by assessing current flow conditions at time of sampling. Sampling may occur within 500 linear feet from the designated coordinates of your S-coded location.

Field/lab datasheet completion

1. Visually assess the stream condition, appearance rating and recreational suitability rating at the sampling site, referring to Appendix B for ratings, abbreviations, and observation codes.
2. On the field datasheet, determine the appearance and suitability of recreation of the stream sampling site using the 1-5 scale provided.
3. Note the stream condition ("interstitial", "low", "high", etc.) on the field sheet.
4. Determine the type of sampling equipment used at the site; bridge, shoreline, or in-stream sampling. This includes determining if flow will allow for wading.

Photo

1. Photograph the field datasheet header box with site and date visible. This photo will be used for picture file naming to be completed post-trip. Datasheet photos do not require retention.
2. Take a photo facing upstream from the sampling site. Include at least one upstream bank or permanent feature along the shoreline that will help interpret the conditions at the site as the seasons and water level vary throughout the sampling period. Alternatively, it is acceptable to consistently photograph downstream if it provides a better view of general stream physical conditions.
3. Take additional photos that document stream conditions, such as bank erosion, construction sediment, algae, etc.
4. Mark on the field datasheet any comments that will help describe the photos.
5. Instructions for naming and storing photos follow under "Post-trip Requirements".

Field meter measurements

Temperature, specific conductance, DO and pH measurements shall be recorded with a field meter. Place the sensors in a well-mixed, flowing portion of the stream at or near the sampling location. If flow conditions are such that the sensors could be damaged, move to the closest accessible point in the stream that is safe for the equipment. The individual probes or multi-probe sonde can be placed in the water while wading, sampling from the bank, or lowered from a bridge. If wading, place the sonde upstream of sampler.

Use a reliable meter with documented calibration checks. Follow the operation instructions supplied by the manufacturer of your specific meter. General steps to take a measurement follow.

1. Turn on the meter.
2. Lower from a bridge deck or wade into the stream to place sonde in a location with well mixed water with adequate flow.
3. Make sure the sonde is not in the sediment.
4. Allow the sonde to stabilize (or lock).
5. Record the measurements onto your field sheet.

In-stream sampling – wading

1. Enter the stream downstream of the sampling location with the bucket of bottles.
2. Walk upstream to the sampling location and face upstream.
3. Remove the lid from the sample bottle.
4. Without touching the inside of the bottle or lid, lower the bottle upside down into the stream.
5. Invert the bottle below the water surface (elbow depth) and allow it to fill.
6. Raise the bottle to the surface, taking care to avoid any surface material. Return to shore and add preservative where necessary.
7. Cap the bottle.
8. Repeat steps 3 through 7 for any additional bottles.
9. Take transparency reading with the 100 cm Secchi tube according to the instructions below.
10. Take field meter measurements, ensuring that the sensors are not obstructed by vegetation or within the sediment.

In-stream sampling - shoreline

1. Bring telescoping rod, bottles, and field meter to the shoreline adjacent to the sampling site.
2. Ensure the collection bottle on the rod is securely attached. Rinse the bottle three times in the stream.
3. Extend the telescoping rod to the length necessary to reach the point of flow. Dip the rod into the water with the bottle opening facing the water.
4. Invert the bottle and fill from just below the water surface.
5. Carefully retract the rod and bring the collection bottle to shore.
6. Remove the lid from the sample bottle.
7. Without touching the inside of the bottle or lid, pour the contents of the collection bottle into the sample bottle. Add preservative where necessary.
8. Repeat steps 3 through 7 if additional water is required.

9. Fill 100 cm Secchi tube from the telescoping rod collection bottle. Measure the transparency according to the instructions below.
10. Take field meter measurements, ensuring that the sensors are not obstructed by vegetation or within the sediment. If not practical, take measurements from sample bucket.

In-stream sampling - bridge

1. Bring weighted bucket sampler or Van Dorn sampler and necessary bottles to the bridge above the sampling location.
2. Ensure the weighted bucket sampler is securely attached to the rope. Rinse the sampler three times in the stream by lowering the bucket, collecting a water sample and emptying out the bucket.
3. Lower the weighted bucket into the stream. Be sure to carefully uncoil the rope, so that it does not scrape against the bridge wall or pick up excess debris from the bridge deck.
4. Once filled, retrieve the sample, taking care to avoid scraping the rope against the bridge and shaking particles from the rope into the sample. If using the Van Dorn sampler, trip the closing mechanism prior to removing the sampler from the water.
5. Without touching the inside of the bottle or lid, pour the contents of the bucket into the analysis bottles before sediment has time to settle to the bottom of the bucket. Add preservative where necessary.
6. Repeat steps 3 through 5 if additional samples are needed. If collecting a field duplicate for a quality control check, remember to fill these bottles from a separate dip of the bucket sampler.
7. Fill 100 cm Secchi tube from the weighted bucket sampler. Measure the transparency according to the instructions below.
8. Take field meter measurements, ensuring that the sensors are not obstructed by vegetation or sediment. If not practical, take measurements from sample bucket.

100 cm Secchi tube transparency measurement

1. Remove sunglasses. Turn your back to the sun and position the tube to avoid direct sun the full length of the tube.
2. Gently pull up the inside string to remove the black and white Secchi disk from the tube.
3. Fill the tube to the top with water from the sampling bottle or bucket. Let the water drain out of the string guide hole to the zero mark on the tape measure attached to the side of the tube.
4. While looking down into your tube from the top, slowly lower the Secchi disk down into the tube until the disk disappears from sight. When it disappears, stop lowering.
5. While continuing to look down the top of the tube, slowly pull the string to raise the disk until it reappears. Lower and raise the disk until you have found the midpoint between disappearance and reappearance of the disk.
6. Pinch the string against the top rim of the tube to hold the disk at this measured depth of disappearance/reappearance. Look at the side of the tube, across the top of the disk, to see the closest centimeter mark on the tape.
7. Write down this depth, to the nearest centimeter, on your stream data sheet under "Secchi tube depth." If the disk does not disappear, and you see it clearly sitting on the bottom of the tube, record "greater than 100".

Quality assurance/Quality control

Field duplicate (also called field replicate) shall be collected in July of the first monitoring season at each monitoring location for all scheduled parameters. Field blanks (may also be called a sampler blank or equipment blank) shall be collected by each stream monitoring team at one site in July of the first monitoring year. Contact your laboratory to verify the QA/QC labeling they have designated for use.

Guidelines for collecting a field duplicate

1. Label bottles as directed by the lab, ensuring that you identify the sample as a field duplicate. If time is used, record as 1-5 minutes after the original sample is collected.
2. Collect the sample using one of the methods previously described.
3. Add preservative, if needed and place sample bottles in coolers with ice.
4. Be sure to note the appropriate sample type on the COC for a field duplicate.

Guidelines for collecting a field blank (equipment blank):

1. Label bottles as directed by the lab, ensuring that you identify the sample as a field blank. If time is used, record as 1-5 minutes after the original sample is collected.
2. Rinse sampler three times with distilled water.
3. Fill the sampler a fourth time with distilled water and pour into the sample bottles.
4. Add preservative, if needed and place sample bottles in coolers with ice.
5. Be sure to note the appropriate Sample Type on the COC for a field blank.

Chain of custody completion

1. Verify information on the COC matches information on the bottles.
2. Ensure the correct EQUIS Project ID has been added to the form. Only one COC can be used per EQUIS Project ID (i.e. PRJ07081, PRJ07082).
3. Include the correct stream site ID, date, and time.
4. Depth recorded is 0 m for both start and end depth.
5. Duplicate/replicate samples must be recorded in their own row.
6. Document preservative use.
7. Sign and date upon transfer of possession with laboratory receiving staff or shipper.

Shipping preparation

1. Verify that preservatives have been added to the appropriate bottles.
2. Ensure caps on bottles are adequately sealed.
3. Place all sample bottles in coolers with adequate amount of ice to account for shipment/delivery time. Monitoring staff must note that all water quality sample bottles must not exceed 6° C.
4. Ensure that bottles and ice are tightly packed into the cooler to avoid jostling and potential bottle breakage.

Post-trip requirements

Processing photos

At the end of each trip, download and label photos using the following naming protocol.

1. Download photos from the camera.
2. Rename them using the following:
 - S004-552 20150720A.JPG
 - S-code a space date collected YYYYMMDD then a alphabetic identifier if there are multiple pictures
3. Delete the photos of field sheets if taken to help identify specific stream sites.
4. Delete photos from camera.
5. Local partners shall submit photos to the MPCA project manager via, compact disk, flash card or shared online folder.

Data management

Data collected through the SWAG program is characterized by two categories; field observations and recordings and analytical laboratory data. Separate procedure and management practices are required for the collection, storage, and submittal of data collected.

Field observations

All observations documented in the field shall be transferred from the Stream Datasheet to the EQuIS Excel Template. Local partners are not required to submit the Stream Datasheet but must retain a record for future references. The following information must be included within the template

- a. The designated Project ID.
- b. Stream name, S- code ID, date, and time.
- c. Correct observations with correct units of measurement

Laboratory results

All laboratories contracted under the SWAG program are required to submit analytical results to the MPCA electronically. Laboratories shall submit the results as an electronic data deliverable utilizing the LAB_MN feature of EQuIS. Local partners shall coordinate and monitor EDD submittal with their contracted laboratory and retain the hard copies of the results. These documents shall be used at the end of the monitoring season for QA/QC data review. Local partners are not required to transcribe the lab results to the EQuIS Template.

Health and safety

Chemical safety

The most common acid preservatives used in water quality monitoring are sulfuric and nitric acid. Sulfuric acid is used for nutrient preservation and nitric acid is used for metals preservation. Material Safety Data Sheets (MSDS) shall be filed in an easily accessible location near the chemical storage and handling area and consulted for first aid measures and proper handling, storage and disposal requirements. General information regarding preservatives:

1. When handling sample preservatives, always use extreme care; splash-proof goggles and non-contaminating gloves are recommended.
2. Avoid contact between preservatives and skin, eyes, nose and mouth.
3. Sulfuric and other acids will eat through clothing. Immediately wash shoes and clothes that are exposed to acid.
4. Leave ample room at the top of the sample bottle for the addition of preservatives and room for mixing.
5. Store chemicals and preservatives in a safe place. Do not store chemicals where they will be subject to temperature extremes or long-term direct sunlight. Follow storage and handling requirements spelled out in the MSDS.
6. When using pre-measured preservative vials from a lab, dispose of the empty vials in a sealed plastic bag (bags used to ship the vials work well) and dispose of properly.

Road and vehicle safety

One of the most dangerous components of water quality sampling is the risk of injury posed by oncoming traffic. The Minnesota Department of Transportation has guidance relating to road safety. MPCA staff and local partners are required to abide by the requirements when working on Minnesota's roadways. Use of traffic control devices are essential and should be used as needed based on site location.

Whenever possible, park the vehicle in a nearby field approach, driveway or public parking lot. If off road parking is not available, please refer to the Minnesota Temporary Traffic Control Zone Layouts Field Manual January 2014 (<http://www.dot.state.mn.us/trafficeng/publ/fieldmanual>) for guidance. The Temporary Traffic Control Zone Layouts Field Manual 2014 or the most up to date version must be followed. It is recommended that each person have a copy of the manual in the field vehicle.

Different protocols should be implemented depending on location and access to sampling site. In most situations, layouts 2, 5 and 6 can be used. This is dependent on traffic volume.

Traffic control devices

These devices are commonly used in the layout diagrams to direct and warn traffic. MPCA staff and local partners should have these items, as needed based on site location.

Vehicle warning lights – amber in color, should be turned on when parking on the shoulder of the road and visible to drivers from 360 degrees. Vehicle warning lights attract the attention of road users and can result in a potentially hazardous situation.

Work zone warning sign – a 36" x 36" "ROAD WORK AHEAD" sign may be needed depending on the site. Placement should be far enough from vehicle to slow traffic and give drivers adequate time to

react. The appropriate distance is the “A” distance on the back flip out page of the *Minnesota Temporary Traffic Control Zone Layouts Field Manual January 2014*.

Cones – Must be orange, contain retro-reflective bands and be at least 36 inches high. Spend the least amount of time necessary to set up and remove the cones to limit exposure to oncoming traffic.

Personal Protection Gear – High visibility safety apparel with retro-reflective material should be worn at all times. The minimum requirement is a Class 2 safety vest. In low light conditions, additional safety apparel such as a retroreflective hat and pants are recommended.

General sampling safety

The safety of sampling staff is of utmost importance. Water quality samples are to be collected only if conditions allow. Site accessibility and safety precautions can vary significantly from site to site. Collecting samples from a bridge with wide shoulders and speeding traffic can be much different from a remote site requiring a hike into a gorge with an extended pole. In the first instance, flashers, cones and reflective wear are imperative. While in the second instance, safety precautions may involve protective outdoor gear, waders and bug repellent. Regardless, sampling personnel are required to understand the differences in accessibility and safety for each site and plan accordingly.

In no case should a sampler put themselves at risk when sampling rivers or lakes. Water quality samples are to be collected only if defined sampling methods are adhered to. If samples cannot be collected using approved methods, sampling shall not occur.

1. Do not collect samples during adverse weather conditions (presence of lightning, swift current/flooding). If lightning is present, return to the vehicle and wait a minimum of 20 minutes from the last visible lightning flash before returning to the water.
2. Wear a United States Coast Guard certified personal floatation device (PFD) when collecting samples directly from the stream (the wading method).
3. If the stream depth (in feet) multiplied by its velocity (feet per second) exceeds your height (in feet), then do not wade into the water.
4. When wading to collect samples, wear hip boots or waders that protect from the cold, pollutants, and other potentially dangerous field conditions. Be aware of your surroundings while wading; look for debris upstream, use a wading rod or walking stick, if possible, to determine stream bed conditions, especially in turbid conditions.
5. Always let someone know where you are, your planned return time, and what to do if not back (or cannot be reached) by the appointed arrival time.
6. Develop a safety plan. Determine the location and telephone number of the nearest medical centers within your defined sampling area. Determine directions on how to get from the nearest medical centers to your sites in case you need to give directions during an emergency.

Appendix A – Preservation and holding times

Information is specific to the Minnesota Department of Health Environmental Health Laboratory. Consult your specific lab for preservatives, required bottles, and holding times for the analytical methods selected and approved by MPCA QA/QC staff.

Parameter	Sample Collection Method	Container Type	Preservation	Holding Time
Dissolved Oxygen	Meter reading	Field Measurement	None	Instantaneous
pH	Meter reading	Field Measurement	None	Instantaneous
Specific Conductance	Meter reading	Field Measurement	None	Instantaneous
Temperature	Meter reading	Field Measurement	None	Instantaneous
TSS	Grab sample	1 L general chem.	None	7 days
Total Phosphorus	Grab sample	250-mL nutrient	10% H ₂ SO ₄ @ 4 C	28 days
NO ₂ +NO ₃	Grab sample	250-mL nutrient	10% H ₂ SO ₄ @ 4 C	28 days
Chloride	Grab sample	1 L general chem.	4°C	28 days
Sulfate	Grab sample	1 L general chem.	4°C	28 days
E.coli	Grab sample	125 mL bacteria	4°C	8 hours*
Chlorophyll a	Grab sample	petri dish	4°C	30 days
Pheophytin	Grab sample	petri dish	4°C	30 days
Calcium	Grab sample	500 mL metal	20% HNO ₃	6 months
Magnesium	Grab sample	500 mL metal	20% HNO ₃	6 months
Hardness	Grab sample	500 mL metal	20% HNO ₃	6 months
BOD, 5 Day	Grab sample	2 L general chem.	4°C	48 hours

* The MPCA will accept data for samples that have been set up for incubation past the 8-hour hold time. All data up to 24 hours from the time of collection must be qualified if the 8 hour holding time is exceeded. Additionally, documentation indicating the duration of the exceedance shall be provided for all samples exceeding 24 hours. Samples exceeding 30 hours will be evaluated to determine the necessity for makeup sample collection.

Appendix B – Metadata coding for field observations in EQUIS

Additional instructions/information

Metadata forms and data process information located [online](#).

Rating	Appearance definition	Rating	Recreational suitability definition
1A	Clear – crystal, clear transparent water	1	Beautiful, could not be better
1B	Tea-colored – transparent water, which has been colored by dissolved organic matter from upstream bogs or wetlands	2	Very minor aesthetic problems: excellent for body-contact recreation
2	Cloudy – not quite crystal clear; cloudy white, gray or light brown	3	Body-contact recreation and aesthetic enjoyment slightly impaired
3	Muddy – cloudy brown due to high sediment levels	4	Recreation potential and level of enjoyment of the stream substantially reduced (would not swim but boating/canoeing is okay)
4	Green – due to algae growth; indicative of excess nutrients released into the stream		
5	Muddy and Green – a combination of cloudy brown from high sediment levels and green from algae growth	5	Swimming and aesthetic enjoyment of the stream nearly impossible

Abbreviation	Sample type definition
G	Grab – Sampling vessel or bottle filled at one point in water column and cross section of a waterbody
CF	Composite – Flow-weighted with auto-sampler
CO	Composite – Other (describe in comments)
CF-T	Composite – Flow-weighted/time-paced with auto-sampler
D-T	Discrete – Time-paced with auto-sampler
G-DLF	Grab – Disturbed, Low-Flow

Abbreviation	Sampling device definition
SIM	Simple Open Plastic Bucket
ROD	Telescoping Rod with Bottle
ICE1	Ice Conditions Water Sampler (straight rod with bottle attached to lower through ice)
DI	Depth Integrating (USGS type)
WB	Weighted Bucket with Cover
Other	Another type of sampler (describe in notes)
None	Sample collected directly into sample bottle
AS	Automatic Sampler

Stream condition: D=Dry, Z=No Flow, I=Interstitial, L=Low, N=Normal, H=High / SW=Swift, SL=Slow, MO=Moderate / C=Clear, M=Muddy, O=Other

Stream flow (cfs): Note in Field Observations if stream flow was determined by direct measurement, rating curve, L&D gate rating or other.